

DIAL TIMER INSTRUCTIONS

Timer Instructions (See Fig. 1)

1. Insert ON (Green) trippers and OFF (Red) trippers into dial at desired ON and OFF times.
2. Turn dial clockwise () one or more complete revolutions until the arrow head is aligned with the current time of day.

Please note that AM times are in the white section of the dial, and PM times are in the black section of the dial.

Manual Override: Timer may be turned ON or OFF manually, by turning the override knob counterclockwise (). The timer will resume the next scheduled ON and OFF cycle automatically. See Figure 1.

